



For detailed, step-by-step directions, refer to the *Complete Guide to Pool and Spa Care*.

#1



Dip and
remove strip

#2



Wait
15 seconds

#3



Compare pads
to color chart
on bottle

*For best results on Cyanuric Acid test, pH should be between 7.0-8.4 and Total Alkalinity should be at or below 240 ppm.



www.AquaChek.com