



## SolarPill® Instructions

Small pill (4.4oz) treats up to 12,000 gallons Large pill (14.2oz) treats up to 30,000 gallons

### **DIRECTIONS FOR USE**

1. Detach blue piercing tool from white pushpin.
2. Insert blue piercing tool into large center hole. Press firmly against hard surface until plastic is punched through.
3. Turn pill over and pierce two holes on both sides of logo using white pushpin.
4. With pump running, discard blue tool and place pill face up in skimmer for 4-6 hours.

**DO NOT** place chlorine tablets into skimmer at this time. Run the pump for at least 8 hours daily.